

ASSEMBLY INSTRUCTIONS: GRANITE/CRUSHED STONE PLAQUE LAWN STAKES



Figure 1



Figure 2



Figure 3



Figure 4

Assembly Instructions:

1. On one side of each lawn stake, apply a thin bead of adhesive around the top hole (Figure 1).
2. Line up the holes on the back of the plaque with the holes on the adhesive side of the stakes and insert bolts (Figure 2). Make sure there is enough adhesive to form a secure bond between the stake and the back of the plaque.
3. Thread nuts onto bolts and finger tighten (Figure 3).
4. Align stakes so they are at 90 degrees to the bottom of the plaque and parallel to each other. Tighten nuts and bolts until snug (Figure 4). Do not over tighten, or you may damage the plaque.
5. After allowing the adhesive to dry for a minimum of 24 hours, carefully shove stakes into lawn to desired height (Figure 5).



Figure 5

QualArc, Inc.
11300 Trade Center Dr., Ste. A
Rancho Cordova, CA 95742
916-273-1576
Fax 916-635-0228
www.qualarc.com

