

Congratulations on your purchase of a European Home mailbox!

Mounting instructions:

While holding the mailbox open at the desired location, mark the top mounting holes.

Using a level, check that the mailbox is straight.

Mark bottom holes.

Check with level again.

Drill into the wall at the marked locations. Use a $\frac{1}{4}$ " bit for brick or other masonry and a $\frac{1}{16}$ " bit for wood.

For brick or other masonry, use plastic anchors. If drilling into wood, these are not necessary.

If using plastic anchors, insert anchors into holes. Align mailbox with holes. Screw into place.